



MODEL : PK100300 (Pump)



MODEL : PK100300 (Receive Tank)



SPARE PARTS LIST

NO : EFX-2111

REF. NO.	DESCRIPTION	PART NO.	QTY.	REF. NO.	DESCRIPTION	PART NO.	QTY.
1	Cylinder head	3101094	3	22	Bolt set	3B07-SM16*40-A	1
2	Allen bolt set	3B01-M12*055V	12	23	Rear bearing seat	3311037	1
3	Allen bolt set	3B01-M08*055Z	3	24	Breathing cover	2321008	1
4	Cylinder head gasket	2G01-012C	3	25	Hexagon bolt	2B00-SM10*025	12
5	Inlet&Exhaust valve assembly	3B13-AP100	3	26	Front bearing seat	3309042P	1
6	Valve seat gasket	2G03-006C	3	27	Front bearing seat gasket	2G05-009	1
7	Double head screw set	3B11-004-A	12	28	Thrust block set	3312008-A	1
8	Cylinder	3201016G	3	29	Oil seal	2N50-TC50*70*12	1
9	Cylinder gasket	2G04-010	3	30	Pulley	3PBF-115B350	1
10	Piston ring set	3B32-100N	3	31	Fly wheel	3PBF-516*228	1
11	Piston set	3B31-100L	3	32	Hexagon bolt set	3B00-SM08*035AV	6
12	Rod set	3B33-P7567X	2	33	Pulley washer	2B34-13*75*13	1
13	Crank rod bush(2 pieces)	2316002-BX	3	34	Hexagon bolt set	3B00-SM12*050V	1
14	Crankcase	3301129	1	35	Exhaust elbow	2N06-10T10H	1
15	Oil draining plug	2N33-002	1	36	Exhaust three way pipe	2N09-10H10T10H3	1
16	Oil sight gauge set	2303016A	1	37	Exhaust tube set	3B2-10*250	1
17	Oil filling plug set	2319004A	1	38	Air filter	2140011	3
18	Bearing	2N35-32210	2	39	Filter element	2142009	3
19	Crankshaft & balancer	3304027	1	40	Exhaust tube set	3B2-10*265	1
20	Pulley key	2N47-10*8*40	1	41	Rod set	3B33-P7568X	1
21	Rear bearing seat gasket	2G06-003	1	42	Exhaust three way pipe	2N09-10H10T10H4	1

SPARE PARTS LIST

NO : EFX-2111

REF. NO.	DESCRIPTION	PART NO.	QTY.	REF. NO.	DESCRIPTION	PART NO.	QTY.
1	Air tank	3401A061	1	18	Motor feet bolt set	3B08-FM12*42-M	4
2	Ball valve	2413058	1	19	Motor pulley	3PMF-055B3M3810	1
3	Tank wheel	2402004	4	20	Hexagon bolt	2B01-M08*025	2
4	Plate washer	2B30-23*46*12	4	21	V-belt	2N31-B73	3
5	Cotter pin	2N40-W015*14	4	22	Set bracket	3427010	1
6	Check valve	2414032	1	23	Set bracket	3427030	1
7	Unloading elbow	2N06-01T02H	1	24	Hexagon bolt set	3B00-FM08*015W	10
8	Unloading tube set	3B2-02*980F	1	25	Belt guard	3426019	1
9	Exhaust tube set	3B2-10*750	1	26	Bracket	3427021B	1
10	Exhaust manifold	3415012	1	27	Hexagon bolt set	3B00-FM06*015VW	1
11	Nipple	2N01-002	1	28	Magnetic switch seat	3417002	1
12	Pressure switch	2E21-031P	1	29	Ball valve	2413008X	1
13	Pressure relief valve	2406054X	1	30	Hexagon bolt set	3B00-FM12*040V	4
14	Pressure gauge	2D12-25V20K	1	31	Cable	2E02-1521802Y2Y	1
15	Ball valve	2413001X	2	32	Cable	2E02-4030403Y3Q	1
16	Motor base	3421005	2	33	Magnetic switch	2E22-10*5641X	1
17	Motor feet bolt set	3B08-FM12*28-M	4				