


MODEL : TK75-250V (Pump)




SPARE PARTS LIST

NO : EFX-2008

REF. NO.	DESCRIPTION	PART NO.	QTY.	REF. NO.	DESCRIPTION	PART NO.	QTY.
1	Cylinder head	3101094	1	27	Front bearing seat gasket	2G05-009	1
2	Allen bolt set	3B01-M12*055V	4	28	Trust ring	3312007-A	1
3	Allen bolt set	3B01-M08*055Z	1	29	Oil seal	2N50-TC43*68*12X	1
4	Cylinder head gasket	2G01-012C	1	30	Pulley	3PBF-115B243	1
5	In. & Ex. valve assembly	3B13-AP100	1	31	Fly wheel	3PBF-516*228	1
6	Valve seat gasket	2G03-006C	1	32	Hexagon bolt set	3B00-SM08*035AV	6
7	Double head screw set	3B11-004-A	8	33	Pulley washer	2B34-13*75*13	1
8	Cylinder	3201016G	1	34	Hexagon bolt set	3B00-SM12*050V	1
9	Cylinder gasket	2G04-010	2	35	Exhaust elbow	2N06-10T10H	3
10	Piston ring set	3B32-100N	1	36	Pressure relief valve	2406020	1
11	Piston set	3B31-100L	1	37	Exhaust tube set	3B2-10*700	1
12	Rod set	3B33-P7560X	1	38	Air filter	2140011	1
13	Rod bush(2 pieces)	2316002-BX	2	39	Filter element	2142009	1
14	Crankcase	3301128	1	40	Cylinder head	3101093	1
15	Oil draining plug	2N33-002	1	41	Hexagon bolt set	3B01-M10*050V	4
16	Oil sight gauge set	2303016A	1	42	Hexagon bolt set	3B01-M06*055Z	2
17	Oil filling plug set	2319004A	1	43	Cylinder head gasket	2G01-011C	1
18	Bearing	2N35-32209	2	44	In. & Ex. valve assembly	3B13-AP80	1
19	Crankshaft & balancer	3304026	1	45	Valve seat gasket	2G03-005C	1
20	Pulley key	2N47-10*8*40	1	46	Cylinder	3201013	1
21	Rear bearing seat gasket	2G06-003	1	47	Piston ring set	3B32-70N	1
22	Bolt set	3B07-SM16*40-A	1	48	Piston set	3B31-T70	1
23	Rear bearing seat	3311038	1	49	Exhaust elbow	2N06-10T10T92	1
24	Breathing cover	2321008	1	50	Spare tank	3125002	1
25	Hexagon bolt	2B00-SM10*025	12	51	Rod set	3B33-TK7564X	1
26	Front bearing seat gasket	3309032	1				

MODEL : TK75-250V (Receive Tank)



SPARE PARTS LIST

NO : EFX-2008

REF. NO.	DESCRIPTION	PART NO.	QTY.	REF. NO.	DESCRIPTION	PART NO.	QTY.
1	Air tank	3401A110A	1	17	V-belt	2N31-B70	2
2	Check valve	2414032	1	18	Set bracket	3427010	1
3	Unloading elbow	2N06-01T02H	1	19	Set bracket	3427030	1
4	Unloading tube	3B2-02*860F	1	20	Hexagon bolt set	3B00-FM08*015W	10
5	Exhaust tube	3B2-10*700	1	21	Belt guard	3426019	1
6	Pressure gauge	2D12-25V20K	1	22	Magnetic switch seat	3417016	1
7	Bushing	2N02-001	1	23	Magnetic switch	2E22-07*5641X	1
8	Pressure switch	2E21-008X	1	24	Cable	2E02-2530703Y3Q	1
9	Ball valve	2413001X	2	25	Cable	2E02-1521002Y2Y	1
10	Tank plug	3N34-FT60H	1	26	Hexagon bolt set	3B00-FM12*040V	4
11	Exhaust elbow	2N08-04T04TES	1	27	Tank plug	3N34-FT60HT4	1
12	Pressure relief valve	2406054BX	1	28	Motor feet bolt set	3B08-FM10*25-M	4
13	Ball valve	2413058	1	29	Motor seat	3421004B	2
14	Motor feet bolt set	3B08-FM10*38-M	4	30	Ball valve	2413008X	1
15	Motor pulley	3PMF-080B2M3810	1	31	Bracket	3427021B	1
16	Hexagon bolt	2B00-SM08*020	2	32	Hexagon bolt set	3B00-FM06*015VW	1