


MODEL :WE1110A-3(Pump)




SPARE PARTS LIST

NO : EFX-1801

REF. NO.	DESCRIPTION	PART NO.	QTY.	REF. NO.	DESCRIPTION	PART NO.	QTY.
1	Cylinder head	3101-WE11	2	13	Set screw	2B07-SM08*16	4
2	Hexagon socket set bolt	2B01-M06*065	12	14	Cooling fan(L)	2336-WE11L	1
3	Cylinder head seal	2G01-WE11	2	15	Front cover	3309-WE11	2
4	In. & Ex. valve assembly	3B13-WE11	2	16	Cooling fan(R)	2336-WE11R	1
5	Valve seat seal	2G03-WE11	2	17	Running capacitor	2E27-035S45X44	3
6	Cylinder	3201-WE11H	2	18	Hexagon head nut	2B20-FM08	4
7	Piston ring plate	2214-WE06	2	19	Air filter	2140-OTS04	2
8	Piston rod set	3B3-WE11	2	20	Filter element	2142020	2
9	Cylinder support	3201H-WE11H	2	21	Nipple	2N01-WE11	2
10	Motor set	3B8-WE1107	1	22	Exhaust elbow	2N06-04T03HS	2
11	Bearing	2N35-WE11ROD	2	23	Plug	2B17-FW01*03B	4
12	Crankshaft & balancer	3304-WE11H	1				

MODEL :WE1110A-3(Receive Tank)



SPARE PARTS LIST

NO : EFX-1801

REF. NO.	DESCRIPTION	PART NO.	QTY.	REF. NO.	DESCRIPTION	PART NO.	QTY.
1	Air tank	3401A202	1	11	Pressure gauge	2D12-25V14K	1
2	Drain valve	2405012	1	12	Feet block	2439-WE11	12
3	Rubber pad set	3433015-A	4	13	Check valve	2414036X	3
4	Tank wheel	2402005	4	14	Nipple	2N01-01T01TC	3
5	Tank wheel bolt	2418001	4	15	Solenoid valve	2E20-113X	3
6	Exhaust manifold	3415010	1	16	Exhaust sofe tube	2T02-03*0300GJ	3
7	Pressure relief valve	2406052X	1	17	Controller	2E34-GT400D11K37E	1
8	Nipple	2N01-001	1	18	Magnetic switch seat	3417024	1
9	Ball valve	2413001X	2	19	Hexagon bolt set	3B00-FM08*015W	2
10	Pressure switch	2E21-031P	1				